KitchenAid® OVEN PARTS

For Models: KEMC377KBL03, KEMC377KWH03, KEMC377KBT03, KEMC377KSS03
(Black) (White) (Biscuit) (S.Steel)

27" BUILT−IN ELECTRIC
DOUBLE OVEN
THERMAL CONVECTION LOWER
CRISPWAVE MICROWAVE UPPER



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN PARTS

For Models: KEMC377KBL03, KEMC377KWH03, KEMC377KBT03, KEMC377KSS03
(Black) (White) (Biscuit) (S.Steel)

Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	8300653	Installation Instructions
	4456573	Use & Care Guide (Oven)
	8300890	Use & Care Guide (Microwave)
	4450786	Cooking Guide (Label)
	4449066	Cookbook (T/C Oven)
	8302001	Tech Sheet (Oven)
	4449264	Easy Set Guide (Oven)
	4451052	Guide, Easy Use (Microwave)
	3191638	Safer Cooking Tips
2		Trim, Side
	4455430	RH Black
	4455432	RH White
	4455434	RH Biscuit
	4452083	RH S.Steel
	4455431	LH Black
	4455433	LH White
	4455435	LH Biscuit
	4452084	LH S.Steel
	8281236	Screw
3		Hinge Reciever
	4455605	Left Hand
	4455606	Right Hand
4	4448520	Bumper, Door
5	4452490	Spacer, Foam
7	4455864	Top Chassis
	4449809	Screw
9	4452158	Tube, Vent
	3196176	Screw
10	4452163	Lens, Light
11	4448972	Oven Light Assy
	4449748	Screw
12	4452164	Bulb, Light
13	4452336	Insulator, Bottom Vent
14	4455611	Frame, Front
	4449040	Screw
15	4455381	Gasket, Door
16	4452152	Bracket, Mounting
19	4451477	Support, Insulation
	4449809	Screw
20	4451605	Cap, Spacer
21		Rail, Side
	4450583	Right Side
	4450584	Left Side
	4448444	Grommet
	4449154	Screw
25	4455641	Side, Chassis (R.H. & L.H.)
	4449809	Screw
26	4452233	Back, Chassis
	4449809	Screw
27		Liner, Oven (Not serviceable)
29	4455636	Sensor
	4449154	Screw
30	4449845	Bracket, Support
	4449809	Screw
33	4452495	Deflector, Vent
34	4451666	Vent, Center
	4450038	Screw
	3400832	Screw
37	9759243	Thermostat (TOD) (Temp.) SPST
	4449809	Screw
43	4455529	Base, Chassis
	4449809	Screw
49	4448933	Retainer, Gasket
	4449154	Screw
50	4451747	Cover, Back
	4449809	Screw
51		Trim, Bottom
	4455442	Black
	4455444	White
	4455446	Biscuit
	4455146	S. Steel
	3400832	Screw
52	4451755	Chassis, Back

FOLLOWING PARTS NOT ILLUSTRATED

INSULATION

4449315	Insulation, Wrap
4450364	Insulation, Back

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL PARTS

For Models: KEMC377KBL03, KEMC377KWH03, KEMC377KBT03, KEMC377KSS03
(Black) (White) (Biscuit) (S.Steel)



Illus. No.	Part No.	DESCRIPTION
2		Switch, Membrane
	8302684	Black
	8302038	White
	8302039	Biscuit
	8302687	S.Steel
3	8302346	Assy, Control
	4449745	Screw
5	4452260	Spacer, Foam
10		Panel, Control
	4452602	Black
	4452603	White
	4452973	Biscuit
	3400832	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN DOOR PARTS

For Models: KEMC377KBL03, KEMC377KWH03, KEMC377KBT03, KEMC377KSS03

(Black) (White) (Biscuit) (S.Steel)



Illus. No.	Part No.	DESCRIPTION
1	4457126	Door Liner
2		Hinge, Door
	8300571	R.Side
	8300572	L.Side
	4449743	Screw
3	4449253	Glass, Inner
4	4451721	Insulation, Door
5	4457131	Retainer, Glass
	4449809	Screw
7	9759224	Glass, Inner
12		Door Glass, Assy
	4455393	Black
	4455392	White
	4452315	Black−Stainless
	4455394	Biscuit
13		Door Handle
	4452500	Black
	4452501	White
	4452870	Biscuit
14		Bracket, Handle
	4455803	R.Hand
	4455804	L.Hand
	3196184	Screw
15	9759229	Bracket(2nd Glass)
16	9759230	Bracket(3rd Glass)
19	4450361	Shield, Heat
	4449809	Screw
21	4452325	Seal, Door Top
22	4457113	Shield, Heat (Btm)
23		Retainer, Glass−Clip
	4450863	Black
	4450864	White
	4452119	Biscuit
	3400832	Screw
24	9759227	Glass. Inner

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

LATCH PARTS

For Models: KEMC377KBL03, KEMC377KWH03, KEMC377KBT03, KEMC377KSS03
(Black) (White) (Biscuit) (S.Steel)



Illus. No.	Part No.	DESCRIPTION
1	4451759	Vent, Exhaust
2	4455178	Elbow, Vent−Top
3	4455177	Elbow, Vent−Bottom
4	8300791	Bracket, Combo Chassis
5	4451758	Seal, Foam
9	4450407	Baffle, Rear
	4449809	Screw
10	9759481	Latch, Motorized
16	6610168	Blower
	4455191	Plate, Service

IMPORTANT
PRODUCT SAFETY INFORMATION

ADVISE CONSUMERS OF AN ELECTROCUTION HAZARD WITH DO – IT – YOURSELF REPAIRS OF MICROWAVE OVENS.

The U.S. Consumer Product Saftey Commission warns against do – it – yourself repairs of microwave ovens. Microwave ovens use high voltage which makes it particularly hazardous for consumers to remove the cover and touch electrical parts.

STRONGLY RECOMMEND THAT CONSUMERS HAVE PROFESSIONALS REPAIR MICROWAVE OVENS.

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

INTERNAL OVEN PARTS

For Models: KEMC377KBL03, KEMC377KWH03, KEMC377KBT03, KEMC377KSS03

(Black) (White) (Biscuit) (S.Steel)



Illus. No.	Part No.	DESCRIPTION
2	4456104	Element, Broil
	4449154	Screw
3	4457277	Grill, Broiler
4	4457276	Pan, Broiler
5	3181534	Rack, Roasting
6	4448715	Rack, Oven
	9759322	Pad, Rack
7	4452155	Element, Bake
8	4448881	Nut, Hex
9	4451583	Convection Motor
	4449154	Screw
10	4452226	Blade, Fan
11	4448882	Washer, Lock
12	4452227	Nut
13	4451355	Jack, Meat Probe
14	4448948	Probe, Meat
15	4455036	Tray, Bake
17	4450039	Cover, Bake Tray
	4449809	Screw
20	4452157	Element, Convection
	4449154	Screw
21	4448418	Cover, Fan
	4449154	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET AND STIRRER PARTS

For Models: KEMC377KBL03, KEMC377KWH03, KEMC377KBT03, KEMC377KSS03

(Black) (White) (Biscuit) (S.Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET AND STIRRER PARTS

For Models: KEMC377KBL03, KEMC377KWH03, KEMC377KBT03, KEMC377KSS03

(Black) (White) (Biscuit) (S.Steel)

Illus. No.	Part No.	DESCRIPTION
1	4375299	Bracket, Capacitor
2	4375313	Screw
3	4375037	Rubber Ring
4	4375038	Screw
5	4375314	Air Duct, Magnetron
6	4375253	Support, Tube
7	4375254	Plug, Ceramic
8	4375255	Bushing
9	4375256	Reflector
10	4375257	Chamber, Reflector
11	4375315	Damper
12	4375260	Duct, Inlet
13	4375316	Insulation, Switch
14	4375322	Fan Wheel
15	4375317	Duct, Air
16	4375264	Block, Slide
17	4375248	Cover Plate, Upper
18	4375035	Screw
19	4375318	Lens, Lamp
20	4375319	Spring
21	4375320	Reflector
22	4378400	Pan Handle
23	4375276	Rack
24	4375191	Crisp Plate
25	4375020	Capacitor
26	4375072	Magnetron
27	4375321	Fuse
28	4375231	Block, Fuse
29	4375278	Motor, Blower
30	4375279	Thermostat
31	4375079	Thermostat
32	4375281	Thermostat
33	4375282	Q Tube Assembly
34	4375286	Transformer
35	4375344	Ring Assembly
36	4375345	Shaft
	CABINET PARTS	
37		Hinge, Door
	4375323	Left Side
	4375324	Right Side
38	4451008	Torsion Spring
39		Bracket, Hinge
	4375327	Left
	4375328	Right
40	4375329	Inlet
41	4375330	Door Strap
42	4375331	Grill Plate
43	4375332	Bracket, Thermostat
44	4375333	Fan Cap
45	4375334	Fan Cap Bottom
46		Holder, Switch
	4375335	Left
	4375336	Right
47	4375337	Isolation Plate
48	4375338	Cover Plate (Lower)
49	4375339	Door Plate
50	4375340	Inner Frame
51		Plate, Side
	4375342	Left
	4375341	Right
52	4375343	Turntable
53	4375346	Switch
54	4375347	Motor, Turntable
55	4375348	Light
56	4375349	Rectifire
57	4375350	Cable
58	4375351	Lamp Holder

MICROWAVE COMPARTMENT PARTS

For Models: KEMC377KBL03, KEMC377KWH03, KEMC377KBT03, KEMC377KSS03
(Black) (White) (Biscuit) (S.Steel)



Illus. No.	Part No.	DESCRIPTION
5		Support Rails
	4452551	Right Side
	4452552	Left Side
	4449809	Screw
11	4452547	Rear Channel
	4449809	Screw
	4449154	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP VENTING PARTS

For Models: KEMC377KBL03, KEMC377KWH03, KEMC377KBT03, KEMC377KSS03

(Black) (White) (Biscuit) (S.Steel)



Illus. No.	Part No.	DESCRIPTION
1	4450377	Cover, Top
	4449809	Screw
2	4448935	Baffle, Blower
	1180485	Screw
3	4450920	Blower
	4449809	Screw
4	4451789	Plate, Mounting Transformer
5	6610122	Transformer, (Lights)
	4449809	Screw
6	4450366	Exhaust Duct
7	4450027	Bracket, Duct
8	4449964	Grommet
	4449809	Screw
	112432	Nut
9	4454949	Holder, Fuse
	4449154	Screw
10	4454976	Fuse
11	4449868	Block, Terminal
	3400080	Screw
12	4452559	Side, Combo
	4449809	Screw
13	4456144	Vent, (Control Panel)
	4450038	Screw
14		Side, Control Top
	4451597	Right
	4451598	Left
	4449809	Screw
15	9759135	Back, Control
	4449809	Screw
16	4450550	Cover, Top Rear
	4449809	Screw
17	4448664	Clamp
	4449809	Screw
18	4452366	Cover, Top Front
	4449809	Screw
19	4455038	Transformer, Control Panel
20	4452247	Plate, Cover
	4449809	Screw (4)
21	4451934	Suppressor
22	9752759	Relay

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MICROWAVE DOOR PARTS

For Models: KEMC377KBL03, KEMC377KWH03, KEMC377KBT03, KEMC377KSS03

(Black) (White) (Biscuit) (S.Steel)



Illus. No.	Part No.	DESCRIPTION
9	4448937	Glass, Middle
10	4450945	Frame, Door
	4450038	Screw
13	4450265	Tape, Foam
14		Bracket, Mounting
	4449141	Right Side
	4449142	Left Side
	4449809	Screw
15	4449083	Filler, Side
	4449809	Screw
16		Handle, Door
	4452500	Black
	4452501	White
	4452870	Biscuit
	4455850	S.Steel
	3196184	Screw
17		Glass, Outer
	4452210	Black
	4452788	White
	4452994	Biscuit
	4452258	S.Steel
24	4452330	Bracket, Handle
	3196184	Screw
25		Retainer, Glass−Clip
	4450863	Black
	4450864	White
	4452119	Biscuit
	4451432	S.Steel

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MISCELLANEOUS PARTS

For Models: KEMC377KBL03, KEMC377KWH03, KEMC377KBT03, KEMC377KSS03
(Black) (White) (Biscuit) (S.Steel)

Illus. No.	Part No.	DESCRIPTION

PAINT, TOUCH−UP (1/2oz.)

72017	White
261869	Cord Brown
72032	Black
4392899	Biscuit

PAINT, SPRAY

350930	White
261900	Citrine White
830864	Black
4392901	Biscuit

ADHESIVE

591014	Adhesive Loctite (1/3 oz.)
482338	Sealer, Silastic (3 oz.)

Illus. No.	Part No.	DESCRIPTION

SPLICING WIRES−−25FT. LENGTH

242828	Wire (12 Ga. 150 c Black)
242820	Wire (14 Ga. 150 c Black)
242821	Wire (14 Ga. 150 c Blue)
242822	Wire (14 Ga. 150 c Brown)
242830	Wire (14 Ga. 200 c Brown)
242823	Wire (14 Ga. 150 c Green)
242824	Wire (14 Ga. 150 c Orange)
242829	Wire (12 Ga. 150 c Red)
242825	Wire (14 Ga. 150 c Red)
242831	Wire (14 Ga. 200 c Red)
242826	Wire (14 Ga. 150 c White)
242827	Wire (14 Ga. 150 c Yellow)
242832	Wire (14 Ga. 200 c Yellow)

Illus. No.	Part No.	DESCRIPTION

FOLLOWING PARTS NOT ILLUSTRATED

4378950	Filler Kit (BL)
4378951	Filler Kit (WH)
4378952	Filler Kit (AL)
814381	Kit, Pin Hinge
4448950	Screw, Installation

WIRING HARNESS PARTS

8301909	Harness, Latch
4449809	Screw
8301922	Harness, Main
4450831	Ground (M/W)
4450800	Screw
4449809	Screw
4450950	Conduit, Combo
4450800	Screw
313438	Clip, Harness
4452222	Spacer, Harness
4454835	Tie, Cable